




QUICK REFERENCE















Number of copy sets


of Sets

Display job list

Display Quick Copy screen









Copy operations - Basic copy screen


Copy


Register a copy program













2. Tap Scan/Fax in the main menu.

4. Select the desired type of destination.

7. Specify the next destination and confirm with Yes.

3. Tap Add. Type.

6. Tap Add Dest.

9. Tap Start. The file is sent.

5. Specify a destination.

The destinations categorized into Favorite are displayed.

8. Repeat Step 6 and 7 until all desired destinations are specified.





